


CONNECTINGS



- 1) AES/EBU output.
- 2) Optical digital output.
- 3) Coaxial digital output.
- 4) Power connection.
- 5) ON/OFF switch.

DETAIL OF FUNCTIONS



- 6) Top CD loader: never forget to put the clamber on the CD before closing the trapdoor.
- 7) Reverse track skip^(*).
- 8) Forward track skip^(*).
- 9) Repeat.
- 10) Standby indicator.
- 11) Display.
- 12) Play/Pause.
- 13) Stop: Playback stops and/or cancels all programs, random play and A-B Repeat.
- 14) Standby/start operation.

^(*)When the device is in standby, allows access to the converter section.

REMOTE CONTROL

Keys 7 to 14 have the same functions on the remote control as on the front panel.

15) DISP: Turns off the display.

16) CD/DAC: Inactive.

17) Fast forward.

18) Fast forward.

19) PROG: Allows you to program sequences: press PROG then use keys 7 and 8 to select a track, then PROG again to add this track to the program, and so on. In STOP, the total time of the program is displayed on the right, the number of programmed tracks on the left. Press PLAY to play the program, press STOP twice to erase the program.


20) SHUF: Random playback of the tracks on the disc (the word S is displayed). Each track is only played once.

9) REP: Disc repeat: repeats the track (R1 is displayed) or the disc (R is displayed).

21) A-B repeat: During disc playback, pressing once specifies a start point (A) and pressing again specifies an end point (B). The selected A-B track is played repeatedly.

22) TIME: Time mode selector: pressing 7 repeatedly displays:

- the time of each track.
- the remaining time of each track.
- the total time since the beginning of the disc.
- the total remaining time of the disc.



E.C. MARKING

E.C. marking certified the conformity with low tension directive 73/23/CEE, directive CEM 89/336/CEE and national transpositions.

WARRANTY CONDITIONS

The guarantee is **two years** period from date of purchase. We recommend you to ask your dealer to fill the guarantee and to conserve it. The guarantee is only available for appliance which have been use correctly.

CLEANING

Before any cleaning, switch off your amplifier. Use a soft and dry rag to clean up the appliance. Never use acetone, white-spirit, ammoniac, or any kind of product containing abrasive agent. Never try to clean up inside the appliance.

COMPATIBILITY

This player allows the reading of CD, CD-R and CD-RW discs.



TECHNICAL DATA

Power supply:	30 VA + 1,6 VA
Total capacitive:	88 000 μ F
Output signal amplitude:	1 V
Consumption:	
- standby	< 0,5 W
- operation	4 to 10 W
Dimensions:	440×340×100 mm
Weight:	12 Kg



CAUTIONS

- **Do not make any plug in when the CD player is on.**
- Put your CD player in a dry and well ventilated place, far from source of heat.
- Do not put something on your CD player.
- Avoid any short-cut.
- In case of problems, do not attempt to repair, disassemble or reconstruct the unit as this could cause a serious electrical shock.
- Do not put your CD player too close from a Tuner because of disagreement in HF reception.

CD CLAMPER

- This player is equipped with a High performance CD drive with a CD uploader system. Always put the CD magnet clamper on the disc before closing the hatch.



ADVISES

- To optimize the performance of your device, you should switch it on at least half an hour before any listening, the time for the audio stages to reach its ideal working temperature. Your device will give you optimal listening quality after this time-lapse. Between two uses, it is, therefore, preferable to let the device in the standby position so that it remains at its optimum temperature. At night or when you leave your home, it is best to use the main switch to turn off the device.
- To optimize the sound quality of your system, we recommend that you choose good-quality connection cords. Do not hesitate to ask your specialist dealer for advice.

You have just bought a CD player - Drive with an exceptional audiophile performance. We really thank you for your confidence in our products. To get the best part of your CD player, please read carefully this manual.



**YOU WILL FIND
ENCLOSED**

- A DR400 EVO CD player.
- A global ATOLL remote control supplied with 2 CR2032 Lithium batteries.
- A CD clamber.
- A power cord.
- A modulation cable.
- This user manual accompanied by a warranty certificate.

Last update: January 23rd, 2025

ATOLL ELECTRONIQUE®
*is a French Company that designs, manufactures,
and commercializes all its products.*





WARRANTY FORM ~ DR400 EVO

To present to your dealer with the invoice when returning back the appliance:

ATOLL ELECTRONIQUE®
Bd des Merisiers
50370 BRECEY
FRANCE

Date of purchase:

Place of purchase:

Buyer signature:

Dealer Stamp

OWNER'S MANUAL

DR400 EVO

CD PLAYER - PURE DRIVE



.....
www.atoll-electronique.com
.....